



Solar Clock

power saving



63-267
User's Guide

Please read this user's guide before using your clock.

Package contents

- Clock
- User's Guide
- Base
- Quick Start

Features

- Dual power supply
- Snooze function
- Indoor temperature display

① Install battery

You need one AAA alkaline battery (not included) to power on your clock and set your time and alarm. Make sure you match the polarity symbols (+ and -) marked inside.



Battery Notes:

- *Dispose of batteries promptly and properly. Do not burn or bury them.*
- *Use only fresh batteries of the required size and type.*
- *Remove exhausted batteries from the clock. Batteries can leak chemicals that can damage electronic parts.*

② Place Your Clock

Place your clock on the magnetic base.

Set the Clock

1. Press **SET**. The second digits flash.
2. Press ▲ or ▼ to reset to zero.
3. Press **SET** repeatedly to choose hour, minute, year, month and date.
4. Use ▲ or ▼ to adjust the digit.

Set the Alarm

1. Press to enter alarm mode. *AL* shows.
2. Press **SET** to set hour and minute. Use ▲ or ▼ to adjust the digit.
3. Press **SET** to confirm.

The alarm sounds for 40 seconds without interruption. Press **ZZ** to snooze the alarm for 5 minutes. Press any button to stop the alarm for 24 hours.

In alarm mode, press more than once to turn the alarm on or off. appears when the alarm is turned on.

SET

Set your clock and alarm.



In clock mode, press to enter alarm mode.

In alarm mode, press to turn the alarm on/off.

▲ or ▼
Adjust digit.



In alarm mode, press to switch to clock mode.
In clock mode, press to toggle between normal time and daylight saving time.



C/**F** Press to toggle between Fahrenheit and Centigrade display.

ZZ

Press to snooze the alarm for 5 minutes.
Press to turn the key sound on/off.

Reset the Clock

If the clock malfunctions, use a straightened paper clip to press **RESET**. Your clock returns to default settings.



12/**24** Press to toggle between 12-hour and 24-hour format.

Specifications

Temperature Range 0 to +50°C (32°F to 122°F)
Time Display 12 / 24 hours
Year range 1901 - 2099

Limited Warranty

Ignition L.P. warrants this product against defects in materials and workmanship under normal use by the original purchaser for **ninety (90) days** after the date of purchase. IGNITION L.P. MAKES NO OTHER EXPRESS WARRANTIES.

This warranty does not cover: (a) damage or failure caused by or attributable to abuse, misuse, failure to follow instructions, improper installation or maintenance, alteration, accident, Acts of God (such as floods or lightning), or excess voltage or current; (b) improper or incorrectly performed repairs by persons who are not a Ignition L.P. Authorized Service Facility; (c) consumables such as fuses or batteries; (d) ordinary wear and tear or cosmetic damage; (e) transportation, shipping or insurance costs; (f) costs of product removal, installation, set-up service, adjustment or reinstallation; and (g) claims by persons other than the original purchaser.

Should a problem occur that is covered by this warranty, take the product and the sales receipt as proof of purchase date to the place of purchase. Ignition L.P. will, at its option, unless otherwise provided by law: (a) repair the product without charge for parts and labor; (b) replace the product with the same or a comparable product; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of Ignition L.P. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

IGNITION L.P. EXPRESSLY DISCLAIMS ALL WARRANTIES AND CONDITIONS NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND, IF APPLICABLE, THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, SHALL EXPIRE ON THE EXPIRATION OF THE STATED WARRANTY PERIOD.

EXCEPT AS DESCRIBED ABOVE, IGNITION L.P. SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO THE PURCHASER OF THE PRODUCT OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE AND ANY LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT AND ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF IGNITION L.P. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some States do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State. You may contact Ignition L.P. at:

Ignition L.P., 3102 Maple Ave Suite 450, Dallas, TX 75201
02/09

For product support, call **1-866-315-0426**



Protect the environment by recycling used electronics. Go to E-CyclingCentral.com to find an electronic recycling center near you.